

# PROFITEC TREND

**Exclusive OTB HDD 2,5" Enclosure**

**MT5075**



**User's Guide**

## Contents

Package contents .....	2
Features.....	2
Specification.....	2
Compatibility .....	3
Disk Installation.....	3
Hardware connection .....	3
Driver Installation.....	3
Unplugging the hardware .....	4
Hard disk Partitioning.....	5
One Touch Backup feature.....	8

## Package contents

- MT5075 I / MT5075 S
- 2.5" External Enclosure
- USB 2.0 extension cable
- CD Driver
- User Manual

**Note: 1 pc per each**

## Features

- Supports 2.5" HDD with all standard sizes (up to 8 mm thick)
- Data transfer rate: Up to 480 Mbps

### Note: (12Mbps on USB 1.1 operation system)

- No need for extra driver (except on Windows 98)
- Hot-swappable(Plug & Play)
- One Key Backup

## Specification:

Model	MT5075 I	MT5075 S
Interface	USB 2.0	USB 2.0
HDD Supported	PATA (IDE)	SATA

- LED indicators: Power, HDD
- Material: Stainless Steel+ leather+ABS.
- Weight: 123.7 g(case only)
- Dimension: 140.00mm\*86.10mm\*21.50mm
- Power: USB 2.0

**Remark: Specifications are subject to change without prior notice.**

## Compatibility

### PC COMPATIBILITY

**Minimum demands:** Intel processor 350 MHz, 64 MB RAM

**OS Compatibility:** Windows 98 SE/ME/2000/XP/Vista  
USB 1.1 / USB 2.0


### Mac COMPATIBILITY

**Minimum demands:** Apple G3 Processor, 64 MB RAM

**OS Compatibility:** Mac OS 10.2 and higher for USB 2.0  
Mac OS 9.1 - 10.2


## Disk Installation

See as illustration shows:



## Hardware Connection

1. Make sure your computer is in the operation system.
2. Connect enclosure and computer with USB 2.0 cable. Power LED will be on.




3. Then, system will recognize external enclosure automatically. Disk read/write operations are indicated by HDD led.

## Drivers Installation

### Windows 98/ SE

Driver installing steps:


1. Insert the external enclosure driver CD. The Install shield Wizard dialog box will be pop-uped. Click [Next] icon to continue.



2. Select the default option icon to continue , until the setup wizard finished installing the USB disk, then click [Finish] to restart computer.
3. When the installation is completed, the [Safe Remove] icon will appear on the taskbar when device is connected.



### Windows ME, 2000,XP, Vista



No extra driver is required to run under mentioned systems. The system will detect an USB Mass Storage

Device and install the necessary drivers automatically when you plug enclosure into your computer for the first time. Since then, device will be recognized automatically when plugged in to the same USB port.

### MAC OS

- A. This external enclosure is supported by the Mass Storage Support 1.3.5 in Mac OS, no driver is required.
- B. On the Mac OS 8.6, the software Mass Storage Support 1.3.5 has to be installed. Please download it from the website: [www.apple.com](http://www.apple.com)
- C. On the Mac OS 9.0 or above, no driver is required. The hard drive will appear on desktop whenever is plugged in.


### Unplugging the hardware

#### Windows 98 SE

1. Make sure that all relative windows are closed and all running applications that are stored on the external drive are quitted.
2. Double click the Unplug or Eject hardware icon in the taskbar and select the device that you want to remove, and click [Safety Remove]



- When the system pop-up [Confirm device to be stopped], click [OK]. When the green icon disappears, unplug the USB cable from computer.



**Note: Do not unplug or remove the device when the HDD LED is on or blinking.**

### Windows ME,2000,XP,Vista

- Make sure that all relative windows are closed and all running applications that are stored on the external drive are quitted .
- Double click the [safe remove hardware] icon in the taskbar.



- Select [USB Disk] and click the [Stop] icon to safely remove the device.(You can also click first on [Display device components] to show the detailed information of the disk).

- Once system prompts the “USB Mass Storage Device can now be safely removed from the system” you can unplug the USB device.

**Note: Do not unplug or remove the device when the HDD LED indicator is on or blinking.**

### Mac OS


When disconnecting the external enclosure from computer, close all windows and quit all running applications or programs that are stored or operated on the external HDD. Drag the [External Drive] icon into [Trash Bin] to dismount it from the desktop prior to unplugging the external enclosure from the connection port.

### Hard disk partitioning


#### Windows 2000/2003/XP

**Note: For a formatted Hard Drive, proceed to step 2.**



**Step 1.** Click the [Start] icon and then select [Setting], single click on [Control Panel] to open [Control Panel] window. Double click on [Administrative Tools], and then double click on [Computer Management].





**Step 2.** Click on [Disk Management] under [Storage]. Your new hard drive will show the capacity. Right click on [Disk 1] and choose [Initialize Disk]




**Step 3.** Click [Next] in the New Partition Wizard.  
**Step 4.** Input your partition space then click [Next]





**Step 5.** Assign a drive letter for your new Hard drive, and click [Next].  
**Step 6.** Select the options as you like, and select [Perform a quick format] to shorten formatting time, then click [Next].



**Step 7.** Confirm your setting and click [Finish]  
**Step 8.** The formatting status is showing.  
**Step 9.** When the status change to Healthy, your new hard drive is about to be used.



**Step10.** Go to My Computer, you will find the new device in the window.



### Step 3.

- Choose the new drive (1) under [Disk Utilities] and click [Partition].
- Click [Options] to choose format.
- Refer to [Figure 1]. Choose the number of partitions you want.
- Name the new hard drive
- Choose the [Format] icon


## Mac OS X

**Note: For a formatted Hard drive, proceed to step 2.**


**Step 1.** A warning window will pop up for new and unformatted hard drive. Click [Initialize].

**Step 2.** Click [Go] on the desk bar and choose [Utilities], click [Disk Utility].

- Refer to [Figure 2]. Define file system and size of partition. You can make more than one partition or else leave it as default.
- Click [Partition]



**Figure 1:** Choose the partition for your hard drive.



**Figure 2:** Choose the format for your hard drive.

**Step 4.** After the partition is over, an icon with the [Name] you assigned appears on your desktop. Double click the icon to access the hard drive.




## One Touch Backup feature

Enclosure is equipped with “OTB button” to create automatic backup of specified files and folders when connected to computer. To use this feature you have to install software first, you will find it on CD Driver.

## Software installation


1. Open OneButton\_Generic.exe” from CD Driver.
2. Follow on-screen commands to install application.
3. Restart Windows.
4. Program icon will appear on the Windows task bar.




## Using OTB feature

Connect enclosure to computer. Press OTB button or double click on program icon located in task bar. Click „Backup” tab to specify which data should be archived.





In „Source Directories” section use disk and folders tree, find and mark folders you want to backup. In „Destination drive” section select drive letter assigned to external disk. Click “Exit” to finish settings. Push OTB button to make automatic backup of marked data. To restore backup go to „Restore” tab



Select backed up file you want to restore from the backup files list. Click “Restore” to restore files to its original path (it will replace files) or choose “New directories” option to restore files to new destination.

**Note: This HDD enclosure is manufactured according to newest technology and specification. Media-Tech is not responsible for lost data and damaging hard disk.**

For more information, drivers, instruction manuals, please visit our website: **[www.media-tech.eu](http://www.media-tech.eu)**

*Manufacturer is restricting right to modernize and making changes of this device.  
In accordance with continuous development of hardware and software some functions  
demonstrated on pictures might be presented differently in the future.*